



Safety harness secured and ready to be pulled down into grain.



Pulled into grain just below knee level.





Knee level attempting to walk out of grain.



Pulled into grain above knee level.





Cofferdam being put in place.



Cofferdam in place and extrication begins.





Extrication completed.



Time to get the safety harness off and get back to solid ground.